



CLEANING YOUR DUFF™ AIRBRUSH MACHINE:



If you choose to use a cleaning solution, be sure it is food safe. We like to use clear vodka or even clean hot water. With food coloring used in the Duff Airbrush Machine, water will go a long way in keeping your machine clean. Thoroughly flush your

airbrush between color changes and after you use your last color, clean it following the instructions below and hang to dry. If you take good care of your airbrush machine and clean it after each use, it will last. On occasion, you will want to deep clean your airbrush to keep it running smoothly.

WHAT YOU'LL NEED:

- Warm to hot water and/or Vodka (optional)
- Cotton Swab(s)
- Paper towel or lint-free cloth



**DUFF
APPROVED**

www.duff.com



STEP 1:

Empty any remaining airbrush coloring from the cup.




STEP 2:

Using the dropper, add hot water or vodka to the cup to clean.



STEP 3:

Thoroughly swab the cup clean with a cotton swab. Add more water and repeat if necessary.



STEP 4:

Discard any remaining liquid in the cup after cleaning.



**DUFF
APPROVED**

STEP 5:

Fill the cup once again with hot water or vodka.



STEP 6:

Spray the water or vodka through the airbrush onto a towel until it sprays clear. Add more water or vodka if necessary. Discard any leftover water. When finished hang to dry or dry with a lint-free towel.



CLEANING THE NEEDLE:



STEP 1:

Unscrew the handle



STEP 2:

Unscrew the needle chucking nut



STEP 3:


Pull out the needle



STEP 4:

Clean the needle with a clean rag, paper towel or cotton swab. Reassemble the air brush and test spray with clean water or vodka to confirm your Duff™ Airbrush is clean and free of unwanted colorant.

Repeat these steps as needed.



Always use caution when handling sharp objects.